

Model: CMRTSS300

## 300L Solid Door RTS Cabinet

### Overview

- +15°C to +25°C temperature range
- Core temperature display, represents your vaccine vial through **iCOOL** INTELLIGENT COOLING temperature probe
- External digital controller and temperature display
- Battery back up
- Self-closing doors
- Annual service & Calibration available
- Fitted lock with 2 keys



**2 YEAR PARTS & LABOUR WARRANTY**

**ANNUAL SERVICE & CALIBRATION AVAILABLE**

### Key Features




#### Controller

Controller system. Read, record, reset with the touch of one button. Adjustable temperature setting.



#### Battery back up

Battery back up should there ever be a power outage the battery backup will continue to monitor the internal temperature of the fridge.



#### Porthole

Factory fitted porthole enables quick and easy access for any secondary temperature monitoring probes.



#### LED lighting

Low voltage LED lighting improves running cost as no heat is produced. Long lasting.



#### Flexible storage

Multiple shelf locations. Back stop on every shelf provides a flexible storage solution.

## Details

Model: CMRTSS300

|   |  |
|---|--|
| Gross Capacity (litres)   | 308                                      |
| Net Capacity (litres)   | 300                                      |
| Unit External Width (mm)  | 595                                      |
| Unit External Depth (mm)  | 650                                      |
| Unit External Height (mm)   | 1495                                     |
| Product Weight (kg)   | 64                                       |
| Packed Width (mm)   | 650                                      |
| Packed Depth (mm)   | 702                                      |
| Packed Height (mm)  | 1556                                     |
| Packed Weight (kg)  | 70                                       |
| Temperature Range   | +15°C to +25°C                           |
| External Finish, Internal Finish  | Painted Steel, Painted Steel             |
| Battery Back Up   | Yes                                      |
| Door Finish, Door Type, Door Style  | Painted Steel, Solid, Hinged, Right Hand |
| Open Door Sensor  | Yes                                      |
| Lock  | Yes                                      |
| Adjustable Feet (number)  | Yes (2)                                  |
| Porthole  | Yes                                      |
| Porthole Location   | Rear, Middle                             |
| Temperature Display on Panel, Temperature Alarm, Remote Alarm Contacts, Audible Alarms, Visual Alarms | Yes                                      |

|                                   |                                     |
|-----------------------------------|-------------------------------------|
| Number of Shelves                 | 7 (6 full size, 1 small base shelf) |
| Number of Shelf Positions         | 10+                                 |
| Shelf Material                    | Plastic Coated Wire                 |
| Interior Light                    | Yes                                 |
| Light Type                        | LED                                 |
| Light Activation                  | Switch                              |
| Fan                               | Yes                                 |
| Spark Free                        | No                                  |
| Controller Type                   | Digital, External                   |
| Number of Probes                  | 2                                   |
| Probe Type                        | Air & Load                          |
| Ambient Temperature Range         | +10°C to +30°C                      |
| Refrigerment Type                 | R600a                               |
| CFC Free, HCFC Free, Ammonia Free | Yes                                 |
| Voltage Supply                    | 220-240V/ 50Hz                      |
| Certification                     | CE/UK                               |
| Noise Level (dBA)                 | 50                                  |
| Input Power (W)                   | 220                                 |
| Cable Length (cm)                 | 20                                  |
| Energy Consumption (kWh/annum)    | 2.2                                 |

## Related Products



**CMRTSG300**  
300L Glass Door  
RTS Cabinet



**CMDL01**  
Advanced Data Logger  
with LCD Display



**COMBI01**  
Keyless  
Combination Lock